



Switch	Function in "OFF" setting	Function in "ON" setting	Comments
1	Response to triggering the safety input (terminals 33 + 34) while the gate opens: • No response	Response to triggering the safety input while the gate opens: • Gate stops	Terminals 33 + 34
2	Safety input setting: • 4-wire photo eye normally closed contact	Safety input setting: • 2-wire photo relay	Terminals 33 + 34
3	Response to triggering the safety input while the gate closes: • Gate reverses	Response to triggering the safety input while the gate closes: • Gate opens completely Response to triggering the safety input when position DIP 1 = ON: • Gate reverses and stops	Terminals 33 + 34
4	Relay contact: • Time relay	Relay contact: • Gate status display • * For additional settings, see DIP 6	• Terminals 37 + 38 • TorMinal Mem 022
5	Prewarning time warning light: • OFF	Prewarning time warning light: • 3 seconds • Warning light flashes before gate moves	TorMinal Mem 016
6	Only if DIP 4 = ON (status display): • Gate open – relay contact open • Gate closed – relay contact closed	Only if DIP 4 = ON (status display): • Gate open – relay contact closed • Gate closed – relay contact open	Terminals 37 + 38
7	Premature closing (during automatic closing): • OFF	Premature closing (during automatic closing): • ON Closing delay after actuating the photo eye, e.g. after	TorMinal Mem 021